AR68.60-P-5480GW Remove/install sun visor 22.2.12

MODEL 463 as of model year 2013 /model refinement package 2012

- 1 Bolts
- 2 Sun visor
- 3 Bearing



P68.60-2360-11

X	Remove/install		
1	Unhook sun visor (2) from bearing (3) and pivot to side		
2	Remove bolt (1)		
3	Remove sun visor (2) from headliner		
4	Disconnect electrical connector	i Carefully pull electrical connector out of headliner.	
5	,	If necessary i Open cover and unscrew bearing (3).	
6	Install in the reverse order		